




USB TYPE-C STEREO 3D SOUND ADAPTER



AU-MMSC USER GUIDE



Plug USB Audio Sound Adapter into Type-C port of computer or laptop -- make sure "SABRENT" text on USB Audio Sound Adapter is face up.




To use accessories such as headphones, speakers, etc. plug into the green port.
To use accessories such as a microphone, plug into the pink port.



Control accessories plugged in using the volume and microphone controls directly from your computer or laptop.

MAC




NOTE: Some systems may require you to activate the sound adapter through the system settings.

- On most Mac Operating systems
1. Navigate to System Preferences
 2. Click on the "Sound" icon




3. Select USB Audio Device on both “input” and “Output” tabs

WINDOWS



- On most Windows Operating systems
1. From Control Panel click on sound
 2. Under the “Recording” Tab select “Microphone USB Audio Device”



3. Under the “Playback” tab select “Speakers USB Audio Device”
4. Click “Apply”
5. Click “OK”