

USB 3.0 MICRO SD AND SD CARD READER



SD, SDHC, SDXC, MicroSD, MicroSDHC, MicroSDXC, UHS-I



Insert the **CR-T2MS** into an available USB port on your PC or MAC



Insert the memory cards into the CR-T2MS

At this point, the USB 3.0 Flash Memory card is completely installed -- no software drivers are needed to complete the installation.

Thank you for choosing Sabrent

For installation issues please contact: support@sabrent.com



SABRENT, COM