

USB-C UNIVERSAL DOCKING STATION



FEATURES

- 1x USB-C 10Gbps (USB 3.2 Gen 2x1) upstream host port for output expansion
- Dual video output supported through 2x HDMI 2.0 and 2x DP ports DP/DP, DP/HDMI, HDMI/DP, HDMI/HDMI - at up to 4K/60Hz per output with HDCP 1.4+
- 2x USB-C 10Gbps (USB 3.2 Gen 2x1) ports, rear capable of video output simultaneously with the rightmost DP/HDMI pair, and 2x USB-A 5Gbps (USB 3.2 Gen 1x1) ports for external accessories with 5V/1.5A charging and power delivery
- 2x USB-A 480Mbps (USB 2.0) ports for external accessories such as keyboards and mouse
- 1x RJ45 Gigabit Ethernet (1GbE) with network and Internet connection speeds of up to 1000Mbps
- 3x 3.5mm audio ports for audio out, microphone, and audio out/microphone, respectively
 3x 3.5mm audio ports for audio out, microphone, and audio out/microphone, respectively
- 1x microSD and 1x SD card reader slots with SD/TF 3.0, UHS-I (up to 104MBps) support
- LED status lights for simple operational indicators
- . 120W (20V/6A) power adapter to supply all ports and device

PACKAGE CONTENTS


- . USB-C Universal Docking Station
- · USB-C cable (70cm)
- 120W (20V/6A) power adapter
- User manual

SUPPORTED OPERATING SYSTEMS

- Windows
- · macOS




PRODUCT OVERVIEW



- A. USB-A 5Gbps ports
- B. UHS-I SD/microSD card slots C. Headphone/microphone jack
- D. USB-C 10Gbps port
- E. USB 2.0 ports
- F. Headphone jack
- G. Microphone jack


- H. Power jack
- I. USB-C 10Gbps port to host for I/O and charging
- J. Gigabit Ethernet port
- K. USB-C 10Gbps port with display output support
- L. DisplayPort ports
- M. HDMI ports

GETTING STARTED



A. Plug the adapter into an available outlet and connect it to the docking station's power jack (H). B. Insert the included USB-C cable into the USB-C upstream port on the docking station (I) and connect the other end of the cable to an available Thunderbolt or USB port on your host PC, tablet, or other compliant USB-C device.





- C. Download and install the latest display drivers by visiting: http://displaylink.com/support/downloads.php and when done, restart your system.
- D. The docking station is now ready to use. Connect your display(s) and other peripherals to expand your system's capabilities.

SABRENT

FOR HELP, COMMENTS, QUESTIONS OR CONCERNS
PLEASE CONTACT OUR TECH SUPPORT TEAM VIA OUR WEBSITE
WWW.SABRENT.COM