



# AQUANTIA®

## AQtion AQC111U USB-Ethernet Dongle Quick Start Guide

### Connection and Driver Installation

To install the AQC111U USB-Ethernet Dongle, perform the following:

1. Obtain a USB v3.1 capable cable and connect the Type-C end of the cable to the Dongle. Connect the other end of the USB cable to the USB Port in your computer.
2. Install the Driver for the Dongle that supports your OS. Drivers can be obtained from Aquantia's website and/or Portal.
3. Connect the Ethernet cable to the Dongle.

### LED Status

The Dongle has two LEDs – one LED indicates the link status and the other LED indicates the link/traffic activity.

#### Link Speed LED Indicator

The Link Speed LED displays the following three states to indicate the link speed:

- **Green:** this lit LED state indicates that a 5Gbps link speed is established.
- **Yellow:** this lit LED state indicates that a 2.5Gbps, a 1Gbps, or a 100Mbps link speed is established.
- **Off:** this unlit LED state indicates that no link has yet been established.

#### Link Activity LED Indicator

The green Link Activity LED displays the following three states:

- **Off:** this unlit LED state indicates that there is no link currently established.
- **On:** this green lit LED state indicates that there is an established link, but there is no traffic.
- **Flashing:** this blinking green LED state indicates that there is traffic on the network.



## Trademarks and Copyrights

**PROPRIETARY AND CONFIDENTIAL:** This document is provided by Aquantia Corp. in connection with its products. Disclosure, reproduction, distribution, and use of the contents of this document is permitted only by the intended recipient(s) and only as expressly authorized by Aquantia. No license under any patents or other intellectual property rights of Aquantia is granted by this document. Aquantia may change the information in this document and any of its products and services at any time without notice.

**DISCLAIMER OF WARRANTIES:** Performance specifications and other information provided by Aquantia are provided “AS IS” without warranties of any kind. Aquantia disclaims all express and implied warranties, including without limitation, the implied warranties of merchantability, fitness for a particular purpose, and non-infringement, as well as any warranty of accuracy or completeness, or any warranty arising from course of performance, course of dealing or usage in trade.

**BUYER RESPONSIBILITIES:** Unless specifically stated, Aquantia products are not authorized or warranted to be suitable for use in medical, military, automotive, aeronautical or life support equipment, nor in applications where the failure or malfunction of our product can be reasonably expected to result in personal injury, death or property damage. Aquantia accepts no liability for inclusion and/or use of our products in such equipment or applications and any such inclusion is at your own risk.

Aquantia is a registered trademark of Aquantia Corp., and Aquantia and the Aquantia logo are trademarks of Aquantia Corp. Other trademarks in this document are the property of their respective owners.

Copyright © 2019 Aquantia Corp.  
All Rights Reserved.  
Strictly Confidential

AQC111U USB-Dongle Quick Start Guide Revision 0.1 – March 2019