



WIRELESS MOUSE WITH 3 KEYS



MS-WSML USER MANUAL

FEATURES

- Advanced high precision optical sensor
- Ergonomic design for a high-level comfort
- Multifunction wheel for scroll and zoom
- Optical mechanical design for precise tracking on almost any flat surface
- Self-storing nano receiver, for easy travel
- Resolution :1200 DPI
- Frequency: 2405MHz~2476MHz
- Rating:1.5V~20mA


INSTALLING BATTERIES

The Sabrent MS-WSML use AA alkaline batteries

1 Open the back cover


2 Insert the batterie as shown inside the batterie compartment

3 Close the back cover



CONNECTING THE RECEIVER

1 Connect the receiver to an available USB port on your computer

**SELF-STORING NANO RECEIVER**

You can store the nano receiver on the mouse as shown below



FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Please contact our Technical Support Team
for additional troubleshooting**